

Item Number _____

RAM-VB-193 & RAM-VB-193-SW1

RAM No-Drill™ Seat Bases

National Products, Inc.

Vehicle base for the

2014 Chevrolet Silverado 1500*
2015 Chevrolet Silverado 2500
2015 Chevrolet Silverado 3500
2015 Chevrolet Suburban
2015 Chevrolet Tahoe
2014 GMC Sierra 1500
2015 GMC Sierra 2500
2015 GMC Sierra 3500



Complete Vehicle Mount
RAM-VB-193-SW1

SPECIFICATIONS

Placement

Passenger side front floor pan area.

Drilling Required

No - Mounts under passenger side seat between front seat hooks and floor board.

Seat Configuration

Bucket seats.

Construction/Finish

Steel/Black Powdercoat



Vehicle Base
RAM-VB-193

Notes.

*The RAM-VB-193 base WILL NOT FIT the 2014 Chevrolet Silverado 1500 with 40/20/40 bench seat and no pass through console. The RAM-VB-191 is recommended for this vehicle model.

National Products, Inc.

8410 Dallas Ave S
Seattle, WA 98108
Phone: (206) 763-8361
Fax: (206) 763-9615
Website: www.ram-mount.com
Email: staff@ram-mount.com



Item Number _____

RAM-VB-193 & RAM-VB-193-SW1

RAM No-Drill™ Seat Bases

National Products, Inc.

Vehicle base for the

2014 Chevrolet Silverado 1500*
2015 Chevrolet Silverado 2500
2015 Chevrolet Silverado 3500
2015 Chevrolet Suburban
2015 Chevrolet Tahoe
2014 GMC Sierra 1500
2015 GMC Sierra 2500
2015 GMC Sierra 3500



INSTALLATION INSTRUCTIONS

1. Carefully remove plastic trim if installed over the front and rear seat leg locations. Note that after installation, some of these trim pieces may need to be modified to re-install around or over the installed base.
2. Move the passenger side seat to its most forward position. Using a T50 torx bit, remove the two rear seat leg bolts. Once the bolts are removed, move the seat all the way using the seat adjustment lever or switch.
3. You can tilt the seat forward and gently lift to free the front seat leg hooks from the floor. With the seat free, set it back down and allow it to lean back so there is room to place the base over the exposed slots in the floor.
4. With the base positioned over the hook slots, gently lift and tilt the seat forward so the hooks can be re-inserted through the opening in the base and into the floor pan. The door side rear seat leg has a positioning pin that must be aligned to allow the seat to properly rest in its original position.
5. The front of the rectangular openings of the base should be at the front edge of the seat track on both sides when properly set. There may be some resistance but the base can be slid back and forth to position it properly prior to securing the T plates in step 6.
6. Angle the T plates under the seat track and lower them over the studs. Using the washers and nuts provided, secure the T plates to the base. As these nuts are tightened down, the base will be locked into place.
7. With the base secure, move the seat to its most forward position using the seat lever or switch. Re-install the two bolts previously removed using the T50 torx bit. Fully tighten and replace trim if desired. Note that as previously stated, some trim pieces may need modification in order to be re-installed.

National Products, Inc.

8410 Dallas Ave S
Seattle, WA 98108
Phone: (206) 763-8361
Fax: (206) 763-9615
Website: www.ram-mount.com
Email: staff@ram-mount.com

